

Wrekin BR-WSSD-FL Deluxe Gravity Water Filter System with Stainless Steel tap Brushed Stainless Steel Finish



Assembly, Operating and Maintenance Guide

- The system is designed to be free standing on a stable surface
- The WSSD-FL is supplied with Wrekin ceraULTRA (CF174W) candles
- Should only be used for the treatment of cold water
- Is designed to filter out bacteria and other chemical contaminants
- Please thoroughly wash both hoppers in hot soapy water to remove any remnants of the manufacturing process before assembling the candles
- Discard the first batch of filtered water to prime and flush the filters
- Please note that if water is drawn from the bottom hopper while there is still water in the top hopper, a vacuum can be created slowing the flow from the tap. A slight adjustment of the top hopper will remedy this effect.

CERAMIC FILTER ASSEMBLY

Fit the knob onto the lid by inserting the screw through the hole in the lid
screw the knob onto the screw until hand tight only

Remove the protective packaging from the filter candles

Place the rubber sealing washer over each of the filters threaded mounting spigot – See Diagram below

Place the ceramic candle through the hole of the top chamber

Secure each candle in place by screwing the Wing Nut onto the threaded stem – Hand tight only. **DO NOT OVER TIGHTEN**. Place the top chamber onto the bottom chamber.

FILTER OPERATION

Ensure the outlet tap is in the off position – See Picture above

Fill the top chamber with water – Do not overfill and replace the lid

Leave to allow the water to filter through the ceramic candle. The max flow rate will be achieved once the candles are full saturated after 2–3 passes

At this stage check for leaks around the tap, tighten if necessary.



CERAMIC FILTER CLEANING

Due to filtration of particulate contaminants from the water during use, the flow of water may reduce over a period of time, depending on the quality of the water being filtered. To restore the water flow a simple clean of the elements can be carried out as follows.

Remove the candles by unscrewing the wing Nuts

- Hold the candle in a bowl of water or under cold running water
- Take care to avoid contamination of the open ended threaded mount by keeping this clear of the water. NEVER use soap or detergents
- Take a soft bristle brush or lightly abrasive pad and cup it around the circumference of the ceramic candle applying gentle pressure and

slowly work down the length of the candle ensuring that the whole surface is evenly cleaned. Replace back into the top hopper as per the assembly instructions.

NOTE: If the system is to be left unused for long periods, it is essential to clean and dry the unit down and allow the candles to fully dry out before storage.